



Drop Down Ladder Racks

Passenger Side Driver Side



Clamp & Lock Ladder Racks

Passenger Side Driver Side



Crossbar Racks

2 Bars 3rd Bar



Cargo Racks (5 Crossbars)

	Passenger Side	Driver Side	Passenger Side	Driver Side	2 Bars	3rd Bar	
GM							
CHEVY EXPRESS, GMC SAVANA Factory Preassembled Double Drop Down Rack *Required Mount Kit	4092L* 4095L*	40963	4082L*	4081L	40823	40824	40890* 4089C
FORD							
TRANSIT LOW ROOF Factory Preassembled Double Drop Down Rack *Required Mount Kit	4092L* 4095L*	40963	4082L*	4081L	40821*	40822	40890* 4089T
TRANSIT MID/HIGH ROOF (* MID ROOF) *Required Mount Kit	4099H*	40913					
TRANSIT CONNECT (Mount Kit Included)	40933	40943	4080L	4081L	40821	40822	80060
MERCEDES							
METRIS Factory Preassembled Double Drop Down Rack *Required Mount Kit The 4092L, 4082L & 40821 racks will only fit 126" WB Metris vans	4092L* 4095L*	40963	4082L*	4081L	40821	40822	80060* 8006M
SPRINTER STANDARD ROOF *Required Mount Kit	4097M* 4081S	40983			40821	40822	40890* 4089T
SPRINTER HIGH ROOF *Required Mount Kit	4099H* 4081S	40913					
NISSAN							
NV LOW ROOF Factory Preassembled Double Drop Down Rack *Required Mount Kit	4092L* 4095L*	40963	4082L*	4081L	40821	40822	40890* 4089T
NV HIGH ROOF *Required Mount Kit	4099H* 409ND	40913					
NV200 (Mount Kit Included) 40821 w/2 Retractable Ratchet Straps	40933	40943	4080L	4081L	40821 40819	40822	80060
RAM							
PROMASTER LOW ROOF *Required Mount Kit	4097M* 4081P	40983			40821* 40918	40822	40890* 4089P
PROMASTER HIGH ROOF *Required Mount Kit	4099H* 4081P	40913					
PROMASTER CITY (Mount Kit Included)	40933	40943	4080L	4081L	40821	40822	80060

For detailed product information and accessories visit: kargomaster.com

v3.19 100421



Drop Down Ladder Racks

Passenger Side Driver Side



Clamp & Lock Ladder Racks

Passenger Side Driver Side



Crossbar Racks

2 Bars 3rd Bar



Cargo Racks (5 Crossbars)

GM

CHEVY EXPRESS, GMC SAVANA
Factory Preassembled Double Drop Down Rack
*Required Mount Kit

4A93L* 4A96L
4A95L*
409CD

4A82L* 4A81L
408CC

4A823 4A824

8016A*
4089C

FORD

TRANSIT LOW ROOF
Factory Preassembled Double Drop Down Rack
*Required Mount Kit

4A93L* 4A96L
4A95L*
409TD

4A82L* 4A81L
408TC

4A821* 4A822

8016A*
4089T

TRANSIT MID/HIGH ROOF (1 MID ROOF)
Factory Preassembled Double Drop Down Rack
*Required Mount Kit

4A99H* 4A91H
4A95H*
409TD

TRANSIT CONNECT (Mount Kit Included)
Factory Preassembled Double Drop Down Rack
*Required Mount Kit

4A97L 4A98L
4A95C

4A80L 4A81L

4A821 4A822

8010A*
4089D

MERCEDES

METRIS
Factory Preassembled Double Drop Down Rack

4A97L 4A98L
4A95C

4A80L 4A81L

4A821 4A822

SPRINTER STANDARD ROOF
Factory Preassembled Double Drop Down Rack
*Required Mount Kit

4A93M* 4A96M
4A95M*
4081S

4A821 4A822

8016A*
4089T

SPRINTER HIGH ROOF
Factory Preassembled Double Drop Down Rack
*Required Mount Kit

4A99H* 4A91H
4A95H*
4081S

NISSAN

NV LOW ROOF
Factory Preassembled-Assembled Double Drop Down Rack
*Required Mount Kit

4A93L* 4A96L
4A95L*
409ND

4A82L* 4A81L
408NC

4A821 4A822

4089A*
4089T

NV HIGH ROOF
Factory Preassembled Double Drop Down Rack
*Required Mount Kit

4A99H* 4A91H
4A95H*
409ND

NV200
Factory Preassembled Double Drop Down Rack
*Required Mount Kit

4A97L 4A98L
4A95C

4A80L 4A81L

4A821 4A822

8010A*
4089D

PROMASTER STANDARD ROOF
Factory Preassembled Double Drop Down Rack
*Required Mount Kit

4A93M* 4A96M
4A95M*
4081P

4A821* 4A822
40918

8016A*
4089P

PROMASTER HIGH ROOF
Factory Preassembled Double Drop Down Rack
*Required Mount Kit

4A99H* 4A91H
4A95H*
4081P

PROMASTER CITY (Mount Kit Included)
Factory Preassembled Double Drop Down Rack
*Required Mount Kit

4A97L 4A98L
4A95C

4A80L 4A81L

4A821 4A822

8010A*
4089D