

THRESHOLD - ALUMINUM DIAMOND PLATE SIDE AND REAR DOOR - TRANSIT

Part # : 40463



Aluminum Diamond Plate Side and Rear Door Threshold

Ford Transit Rear and Curbside Door Aluminum Diamond Threshold Kit

The product includes plus nuts required for installation. Consider purchasing our Plus Nut Tool (#P9902) if you don't already have a plus nut installation tool.

Features

- · Holman Aluminum Thresholds replace the factory thresholds
- Durable and attractive
- Easily installed in any wheelbase Ford Transit van
- · Kit includes both curbside and rear door thresholds

Vehicle Fit

Ford Transit van