


Holman

Installation Guide

40620



* Partition sold separately.

Holman
Rancho Cordova, CA 95742
800-343-7486
InstallationSupport@Holman.com

PLEASE READ ALL INSTRUCTIONS AND WARNINGS PRIOR TO ASSEMBLING, INSTALLING, AND USING THIS PRODUCT.

Table of Contents

Tools Needed	1
Before You Begin	1
Parts List	1
Install Door Lock to Partition.....	2



Tools Needed

10mm Socket and Wrench	27mm Box Wrench
------------------------	-----------------

Before You Begin




- Read all instructions prior to assembling or installing any Holman product.

Parts List




NO.	ITEM	PART NUMBER	DESCRIPTION	QTY.
1		A6092-1111	CENTER PANEL LATCH & DOOR LOCK	1
2		12335A43	RUBBER PUSH-ON SEAL	1

Install Door Lock to Partition

- Disassemble lock assembly. **Take notice of position of small tab on rear handle/latch.**
- Insert knob through hole in partition door.
- Using previously removed parts from lock assembly, reassemble lock assembly. **Make sure rear handle/latch are in vertical position and turns counterclockwise.**
- Tighten hardware.



- Attach push-on rubber seal strip to rear flange on door. **Be sure bulb side is facing the passenger side partition.**



Shown without passenger side partition panel for clarity.

INSTALLATION IS COMPLETE.