

## ADHESIVE INSTRUCTIONS DRIVERSCHECK

### DriversCheck

Only EU driver licenses in card format issued by Germany can be scanned using DriversCheck. All other driver licenses can still benefit from the service leveraging a QR-coded seal to be scanned.

**Attention:** The application of the seal absolutely must take place during the initial verification of the drivers license and by the fleet manager. This is to ensure the seal will be applied to a valid driver license. Should this process not be feasible Holman can support leveraging video identification technology.

### 1. Cleaning

Remove any dirt, dust or grease from the surface the seal will be attached to.

### 2. Placing

Chose a free, non-printed area on the driver's license. Under no circumstances may the seal cover any information on the driver's license. On an EU driver licenses in card format issued by Germany the area on the backside above the road signs is ideal.

We recommend the following areas:



### 3. Applying

Stick the seal to the desired location on the driver's license. Stroke your finger multiple times from the middle of the seal in all directions to the outside. Please ensure that no blisters remain under the seal.

**The seal must not be removed and reapplied!**

**Attention:** The glue will reach its full potential after 24 hours. Should you wish to remove the seal it will be damaged and rendered unscannable.