


# Holman

---

## Instruction Guide 40056

---



---

Holman  
Rancho Cordova, CA 95742  
800-343-7486

[InstallationSupport@Holman.com](mailto:InstallationSupport@Holman.com)

---

**PLEASE READ ALL INSTRUCTIONS AND WARNINGS PRIOR TO ASSEMBLING, INSTALLING, AND USING THIS PRODUCT.**

## Warning



**Always check for wires, fuel tanks and lines, brake lines and other important vehicle functionality items prior to drilling and installing all products.**

## Table of Contents

Tools Needed .....	1
Before You Begin .....	1
Parts List.....	1
Hardware .....	1
Step 1 – Determine Installation Location .....	2
Step 2 – Attach E-Track Partition Rail .....	3


## Tools Needed

7/16" Socket and Wrench	7/16", 9/16" Box Wrench
5/16" Drill Bit	Drill



## Before You Begin

- Read all instructions prior to assembling or installing any Holman product.
- **Always locate your installation locations prior to performing any work.**
- **ENSURE SAFETY WHILE INSTALLING OR DRILLING INTO VEHICLE.**

## Parts List

NO.	ITEM	PART NUMBER	DESCRIPTION	QTY.
1		102500	PARTITION BRACKET	1
2		18-40056	40055 HARDWARE KIT	1

## Hardware

ITEM	HARDWARE TO SCALE	PART NUMBER	DESCRIPTION	QTY.
1		0167030	1/4"-20 FLANGED LOCK NUT	20
2		92979A114	1/4"-20 X 5/8" FLANGED HEX HEAD	20


## Step 1 – Determine Installation Location

- Place E-Track partition rail against already installed partition at desired height from floor.
- Using a 5/16" drill bit, drill one hole. Using one 1/4" x 5/8" flanged hex bolts and a 1/4" flanged lock nut, loosely bolt e-track to partition. **ENSURE SAFETY PRIOR TO DRILLING.**



**Be sure the bolt head is on the cab side of the partition.**

- Level E-Track partition rail and drill the remaining nineteen hole locations onto the partition.





**Step 2 – Attach E-Track Partition Rail**

- Using nineteen 1/4" x 5/8" flanged hex bolts and 1/4" flanged lock nuts, attach E-Track partition rail to partition.



**Be sure the bolt heads are on the cab side of the partition.**



**GO BACK AND TIGHTEN ALL HARDWARE.**  
**INSTALLATION AND ASSEMBLY ARE COMPLETE.**